

TITAN OILER™

INSTALLATION INSTRUCTIONS

Working Principle

The **Electro-Luber MD™ 2000 TITAN OILER** is a self-contained, microprocessor controlled, motor driven automatic lubricator. The **TITAN OILER** uses gravity to feed oil into a temperature compensating, fixed displacement pump. This dispenses the oil at pressures over 1000 psi. This pressure allows the **TITAN OILER** to be used with long feed line pipework, and it can even cycle progressive distributors, allowing one **TITAN OILER** to feed several bearings. When one or a combination of selector switches are turned on, the unit will activate at selected intervals. (see chart on page 2). At each interval, the **TITAN Oiler** will delivery approximately 2cc. of oil. This output is not affected by temperature or altitude. When the unit is empty It can be refilled by simply pouring oil into the reservoir.

1 year replacement warranty – **MUST USE ATS BATTERY PACKS TO MAINTAIN WARRANTY AND UL LISTED STATUS**



General Information

On installation, it is important to ensure that the bearing or chain, etc. is pre-lubricated with the required oil. If fittings or feed lines are used, these also should be filled with the same oil. The **TITAN Oiler** has a priming nipple for this purpose.

All **TITAN OILER** units have 1/8" NPT female threads.

If the **ELECTRO-LUBER MD™ TITAN OILER** is remotely mounted, use minimum 3/8" O.D. by minimum 1/4" I.D. tubing for up to 200 feet.

It is important to make sure you prime all piping and lube points prior to installing the ELECTRO-LUBER MD™ TITAN OILER.


In low temperature applications use Lowtemp lubricants.

To ensure the success and reliability of your **ELECTRO-LUBER MD™ TITAN OILER**, do not use in temperatures below -4° F or above 131° F (-20° C to 55° C), or in an application requiring over 2000 psi. The **TITAN OILER** unit is designed for single-point applications up to 200 feet or multiple-point using a progressive distribution block up to 60 feet.



This equipment is suitable for use in:

Class 1, Division 2, Groups A,B,C,D; Class II, Division 2, Groups F & G; Class III or non-hazardous locations only.
Maximum T-Code T6 55°C

In Conformity to Eur  rms
Ex nL IIC T3 II 3 G

WARNING: Explosion Hazard – substitution of any components may impair suitability for Class I, II & III, Division 2 locations.

WARNING: Explosion Hazard – batteries must only be changed in an area known to be non-hazardous.

CAUTION: The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble, heat above 100° C (212° F) or dispose of in fire. Dispose of used battery promptly.

Starting Procedure

Fill the reservoir of the **TITAN OILER** with your desired oil. Referring to the dispensing rate chart on page 2, select the dispensing time and amount of lubricant required. Then set the appropriate switch or switches to the setting which corresponds to the period of time it takes to empty the unit. This action activates the unit, and within 1 minute the first cycle will commence dispensing. If the unit is used with a progressive distribution block to feed multiple bearings, the cycle time must be adjusted accordingly. (example: if the unit is feeding a 4 port block, set your **TITAN OILER** to empty 4 times faster than if it was feeding a single bearing).

Operating Procedure

If it is desired to increase or decrease the lubricant dispensing rate during operations, simply click the switch or switches in use to OFF, Then click on the new switch setting for the revised rate.

To turn **OFF** the **ELECTRO-LUBER MD™ TITAN OILER** set all switches to **OFF**.

The **ELECTRO-LUBER MD™ TITAN OILER** can be disconnected at any time without lubricant discharge, but feed lines may empty.

Switch 7 is the purge switch. If your bearing requires an immediate shot of oil, turn **ON** switch 7. When the **TITAN OILER** unit starts operating, turn switch 7 **OFF**. The **TITAN OILER** unit will run for approximately 2 minutes. If you require more purging, repeat the procedure.

LED LIGHT FUNCTIONS:

LED	SIGNAL	SIGNAL TIME	MEANING
Green	1 Flash	Every 20 Seconds	Operation OK
Green	1 Flash	Every 1 Second	Currently pumping oil
Red	1 Flash	Every 20 Seconds	If Internal limit switch counter is faulty, the unit will go into an operational timed failsafe mode.
Red	2 Flashes	Every 20 Seconds	Low battery. Must be replaced shortly.
Red & Blue	1 Flash each	Every 20 Seconds	Oil in reservoir is low and should be refilled shortly.
Blue	2 Flashes	Every 20 Seconds	Unit paused via remote control option (if used here)
Blue	4 Flashes	Every 20 Seconds	Unit paused due to low ambient temperature. Unit will resume operation when temperature goes above 5 degrees F (-15 degrees C).

NOTE – The lubricants dispensed by this equipment are to have flash points greater than 200° F.

Power

The battery packs for the **TITAN OILER** must be changed when the red light flashes, as described above. The batteries should last at least one complete fill cycle, but please note that battery life is affected by temperature, bearing backpressure and unit setting; actual life varies. To change the battery pack, remove the top cover, unplug and remove the old battery, and then install and plug in the new battery pack. The battery packs, complete with connectors, may be purchased directly from the factory. It is recommended that you have a spare battery pack to avoid a prolonged outage.

Optional alternate power sources are available, please consult the factory or your salesperson.

ALWAYS AVOID OVER-LUBRICATING.

Selection of Switch Settings

For reference, a typical medicine dropper is about 2.5cc. To select the switch setting for your application, look down the Daily Output column for the desired output of lubricant. The switches of the **TITAN OILER** are numbered 1 through 7, and correspond to the setting for your selection as shown in the chart below.

Electro-Luber MD™ 2000 TITAN OILER Dispensing Rate Chart

Days to Empty	Cycle Time (hrs)	Approx. Daily Output		Switch 1 (15 day)	Switch 2 (30 day)	Switch 3 (60 day)	Switch 4 (120 day)	Switch 5 (240 day)	Switch 6 (480 day)	Switch 7 (purge)
		ml.	Cl.							
15	0.5	96.0	5.86	ON	OFF	OFF	OFF	OFF	OFF	OFF
30	1.0	48.0	2.93	OFF	ON	OFF	OFF	OFF	OFF	OFF
45	1.5	32.0	1.95	ON	ON	OFF	OFF	OFF	OFF	OFF
60	2.0	24.0	1.46	OFF	OFF	ON	OFF	OFF	OFF	OFF
90	3.0	16.0	0.98	OFF	ON	ON	OFF	OFF	OFF	OFF
120	4.0	12.0	0.73	OFF	OFF	OFF	ON	OFF	OFF	OFF
150	5.0	9.6	0.59	OFF	ON	OFF	ON	OFF	OFF	OFF
180	6.0	8.0	0.49	OFF	OFF	ON	ON	OFF	OFF	OFF
240	8.0	6.0	0.37	OFF	OFF	OFF	OFF	ON	OFF	OFF
300	10.0	4.8	0.29	OFF	OFF	ON	OFF	ON	OFF	OFF
360	12.0	4.0	0.24	OFF	OFF	OFF	ON	ON	OFF	OFF
480	16.0	3.0	0.18	OFF	OFF	OFF	OFF	OFF	ON	OFF
600	20.0	2.4	0.15	OFF	OFF	OFF	ON	OFF	ON	OFF
720	24.0	2.0	0.12	OFF	OFF	OFF	OFF	ON	ON	OFF

Distributed by Digilube Systems Inc.

Phone: 937-487-2209 Fax: 937-748-0597

www.digilube.com

Digilube Systems, Inc.
216 East Mill Street
Springboro, OH 45066

E.&O.E. Rev. 03/16

BS EN ISO 9001:2008
FM 66860

Not responsible for damage or consequential damage beyond replacement or refund of amount paid.
En cas de dommage, la responsabilité d'A.T.S. se limite au remplacement ou au remboursement de l'appareil